## Sputtering Accessories RAM-Bar™ Changing Station

The RAM-Bar<sup>™</sup> Changing Station makes removing and replacing a RAM-Bar<sup>™</sup> during target changes both safe and easy.

The changing station has two stands: one stand cradles the target, and the other stand holds the RAM-Bar<sup>™</sup> as it is removed or inserted.

375 Alexander Drive SW, Owatonna, MN USA • 507-455-9140 sales@sputteringcomponents.com • www.sputteringcomponents.com

A hook, which is stored in the target stand, is included to guide the strap through the target during insertion.

The stands can be easily disassembled for storage.



SPUTTERING (S)